

3 easy steps to find your ProLinx solution

- 1) Find your specific network protocol from the top row of the chart.
- 2) Follow that column down until it intersects with the required application protocol you wish to connect to.
- 3) For pricing, distributor location or additional product information, datasheets and user manuals, please visit www.prosoft-technology.com.

! Red part numbers indicate a wireless gateway.

Application/ Protocol	Protocol/Application											
	A-B Remote I/O	ASCII	Bosch	CLV	'C' Programmable	'C' Programmable with Ethernet	DF1 Master/Slave	DH-485	DNP 3.0 Master	DNP 3.0 Slave	DNP over Ethernet	EtherNet/IP
A-B Remote I/O		5601-RIO-ASCII 5602-RIO-ASCII4					5601-RIO-DFCM 5602-RIO-DFCM4	5601-RIO-DH485	5601-RIO-DNPM	5601-RIO-DNPS	5210-DNPSNET-RIO	5210-DFNT-RIO
ASCII	5601-RIO-ASCII 5602-RIO-ASCII4						5102-DFCM-ASCII3	5102-DH485-ASCII3				5201-DFNT-ASCII 5202-DFNT-ASCII4
Bosch												5201-DFNT-BSCH 5202-DFNT-BSCH4
'C' Programmable					5102-ADM4							
'C' Programmable with Ethernet						5201-ADMNET 5202-ADMNET4						
Command Language Master												5201-DFNT-CLVM 5202-DFNT-CLVM4
DF1 Master/Slave	5601-RIO-DFCM 5602-RIO-DFCM4	5102-DFCM-ASCII3					5102-DFS3-DFM 5102-MCM4-DFCM4	5102-DH485-DFCM3	5102-DNPM-DFCM 5102-DNPM-DFCM3	5102-DNPS-DFCM3	5201-DNPSNET-DFCM 5202-DNPSNET-DFCM4	5201-DFNT-DFCM 5202-DFNT-DFCM4
DH-485	5601-RIO-DH485	5102-DH485-ASCII3					5102-DH485-DFCM3		5102-DH485-DNPM	5102-DH485-DNPS	5201-DNPSNET-DH485	5201-DFNT-DH485
DNP 3.0 Slave	5601-RIO-DNPS						5102-DNPS-DFCM3	5102-DH485-DNPS				5201-DFNT-DNPS
DNP 3.0 Master	5601-RIO-DNPM						5102-DNPM-DFCM3	5102-DH485-DNPM				5201-DFNT-DNPM
DNP over Ethernet	5210-DNPSNET-RIO						5201-DNPSNET-DFCM 5202-DNPSNET-DFCM4	5201-DH485-DNPSNET				5201-DFNT-DNPSNET
Ethernet Global Data												
EtherNet/IP	5210-DFNT-RIO	5201-DFNT-ASCII 5202-DFNT-ASCII4	5201-DFNT-BSCH 5202-DFNT-BSCH4	5201-DFNT-CLVM 5202-DFNT-CLVM4			5201-DFNT-DFCM 5202-DFNT-DFCM4 6202-WA-DFNT-DFCM3	5201-DFNT-DH485	5201-DFNT-DNPM	5201-DFNT-DNPS	5201-DFNT-DNPSNET	
Gareco												5201-DFNT-GRCM 5202-DFNT-GRCM4
HART Analog (4 channels)							5108-DFCM-HART					5208-DFNT-HART
HART Analog (8 channels)							5128-DFCM-HART					5228-DFNT-HART
HART Multi-drop (4 channels)	5607-RIO-HART						5107-DFCM-HART	5107-DH485-HART				5207-DFNT-HART
HART Multi-drop (8 channels)							5127-DFCM-HART	5127-DH485-HART				
Honeywell DE Master (8 channels)	5606-RIO-DEM						5106-DFCM-DEM	5106-DH485-DEM				5206-DFNT-DEM
Honeywell DE Master (16 channels)							5126-DFCM-DEM					
IEC 60870-5-101 Slave	5601-RIO-101S						5102-DFCM3-101S	5102-DH485-101S				5201-DFNT-101S
IEC 60870-5-103 Master	5601-RIO-103M						5102-DFCM-103M	5102-DH485-103M			5201-DNPSNET-103M	5201-DFNT-103M
IEC 60870-5-104 Server	5210-104S-RIO						5201-104S-DFCM 5202-104S-DFCM4	5201-104S-DH485				5201-DFNT-104S
Modbus Master/Slave	5601-RIO-MCM 5602-RIO-MCM4	5102-MCM-ASCII3				5102-MCM4-ADM4	5201-ADMNET-MCM		5102-DH485-MCM3	5102-DNPS-MCM3	5201-DNPSNET-MCM 5202-DNPSNET-MCM4	5201-DFNT-MCM 5202-DFNT-MCM4
Modbus Plus	5310-RIO-MBP	5301-MBP-ASCII 5302-MBP-ASCII4					5301-MBP-DFCM 5302-MBP-DFCM4	5301-MBP-DH485	5301-MBP-DNPM	5301-MBP-DNPS	5303-MBP-DNPSNET	5303-MBP-DFNT
Modbus TCP/IP	5210-MNET-RIO	5201-MNET-ASCII 5202-MNET-ASCII4	5201-MNET-BSCH 5202-MNET-BSCH4				5201-MNET-DFCM 5202-MNET-DFCM4	5201-DH485-MNET	5201-MNET-DNPM	5201-MNET-DNPS	5201-MNET-DNPSNET	5201-MNET-DFNT
PROFIBUS DP Master	5604-RIO-PDPM						5104-DFCM-PDPM	5104-DH485-PDPM	5104-DNPM-PDPM	5104-DNPS-PDPM	5204-DNPSNET-PDPM	5204-DFNT-PDPM
PROFIBUS DP Slave	5605-RIO-PDPS	5105-ASCII-PDPS					5105-DFCM-PDPS	5105-DH485-PDPS		5105-DNPS-PDPS	5205-DNPSNET-PDPS	5205-DFNT-PDPS
PROFIBUS DPV1												5204-DFNT-PDPMV1
ProSoft Wireless Protocol							6202-WA-DFNT-DFCM3					6202-WA-DFNT-DFCM3

Application/ Protocol	Protocol/Application														
	Gareco	HART Multi-drop (4 channels)	HART Multi-drop (8 channels)	Honeywell DE Master (8 channels)	Honeywell DE Master (16 channels)	IEC 60870-5-101 Slave	IEC 60870-5-103 Master	IEC 60870-5-104 Server	Modbus Master/Slave	Modbus Plus	Modbus TCP/IP	PROFIBUS DP Master	PROFIBUS DP Slave	ProSoft Wireless Protocol	
AB Remote I/O		5607-RIO-HART		5606-RIO-DEM		5601-RIO-101S	5601-RIO-103M	5210-104S-RIO	5601-RIO-MCM 5602-RIO-MCM4	5310-MBP-RIO	5210-MNET-RIO	5604-RIO-PDPMV1	5605-RIO-PDPS		
ASCII									5102-MCM-ASCII3	5301-MBP-ASCII 5302-MBP-ASCII4	5201-MNET-ASCII 5202-MNET-ASCII4		5105-ASCII-PDPS		
Bosch											5201-MNET-BSCH 5202-MNET-BSCH4				
'C' Programmable															
'C' Programmable with Ethernet								5202-ADMNET4-MCM4							
Command Language Master															
DF1 Master/Slave		5107-DFCM-HART	5127-DFCM-HART	5106-DFCM-DEM		5102-DFCM3-101S	5102-DFCM-103M	5201-104S-DFCM 5202-104S-DFCM4	5102-MCM4 DFCM4	5301-MBP-DFCM 5302-MBP-DFCM4	5201-MNET-DFCM 5202-MNET-DFCM4	5104-DFCM-PDPM	5105-DFCM-PDPS	6202-WA-DFNT- DFCM3	
DH-485		5107-DH485-HART	5127-DH485-HART			5102-DH485-101S	5102-DH485-103M	5201-104S-DH485	5102-DH485-MCM3	5301-MBP-DH485	5201-MNET-DH485	5104-DH485-PDPM	5105-DH485-PDPS		
DNP 3.0 Slave									5102-DNPS-MCM3	5301-MBP-DNPS	5201-MNET-DNPS	5104-DNPS-PDPM	5105-DNPS-PDPS		
DNP 3.0 Master									5102-DNPM-MCM3	5301-MBP-DNPM	5201-MNET-DNPM		5105-DNPM-PDPS		
DNP over Ethernet							5201-DNPSNET- 103M		5201-DNPSNET-MCM 5202-DNPSNET-MCM4	5303-MBP- DNPSNET	5201-MNET- DNPSNET	5204-DNPSNET- PDPM	5205-DNPSNET-PDPS		
Ethernet Global Data											5201-MNET-EGD				
EtherNet/IP	5201-DFNT-GRCM 5202-DFNT-GRCM4	5207-DFNT-HART		5206-DFNT-DEM		5201-DFNT-101S	5201-DFNT-103M	5201-DFNT-104S	5201-DFNT-MCM 5202-DFNT-MCM4	5303-MBP-DFNT	5201-MNET-DFNT	5204-DFNT-PDPM	5205-DFNT-PDPS	6202-WA-DFNT- DFCM3	
Gareco															
HART Analog (4 channels)											5208-MNET-HART				
HART Analog (8 channels)											5228-MNET-HART				
HART Multi-drop (4 channels)									5107-MCM-HART	5307-MBP-HART	5207-MNET-HART		5507-PDPS-HART	6207-WA-HART	
HART Multi-drop (8 channels)									5127-MCM-HART					6227-WA-HART	
Honeywell DE Master (8 channels)									5106-MCM-DEM	5306-MBP-DEM	5206-MNET-DEM		5506-PDPS-DEM		
Honeywell DE Master (16 channels)									5126-MCM-DEM2						
IEC 60870-5-101 Slave									5102-MCM3-101S	5301-MBP-101S	5201-MNET-101S	5104-101S-PDPM	5105-101S-PDPS		
IEC 60870-5-103 Master								5201-104S-103M	5102-MCM3-103M	5301-MBP-103M	5201-MNET-103M		5105-103M-PDPS		
IEC 60870-5-104 Server							5201-104S-103M		5201-104S-MCM 5202-104S-MCM4	5303-MBP-104S	5201-MNET-104S	5204-104S-PDPM	5205-TS-104S-PDPS		
Modbus Master/Slave		5107-MCM-HART	5127-MCM-HART	5106-MCM-DEM	5126-MCM-DEM	5102-MCM3-101S	5102-MCM-103M	5201-104S-MCM 5202-104S-MCM4	5102-MBS3-MBM 5102-MCM4-DFCM4	5301-MBP-MCM 5302-MBP-MCM4	5201-MNET-MCM 5202-MNET-MCM4	5104-MCM-PDPM	5105-MCM-PDPS	6201-WA-MCM	
Modbus Plus		5307-MBP-HART		5306-MBP-DEM		5301-MBP-101S	5301-MBP-103M	5303-MBP-104S	5301-MBP-MCM 5302-MBP-MCM4		5303-MBP-MNET	5304-MBP-PDPM	5305-MBP-PDPS		
Modbus TCP/IP		5207-MNET-HART		5206-MNET-DEM		5201-MNET-101S	5201-MNET-103M	5201-MNET-104S	5201-MNET-MCM 5202-MNET-MCM4	5303-MBP-MNET		5204-MNET-PDPM	5205-MNET-PDPS	6201-WA-MNET	
PROFIBUS DP Master						5104-101S-PDPM		5204-104S-PDPM	5104-MCM-PDPM	5304-MBP-PDPM	5204-MNET-PDPM			6201-WA-PDPM	
PROFIBUS DP Slave		5507-PDPS-HART		5506-PDPS-DEM		5105-101S-PDPS	5105-103M-PDPS	5205-104S-PDPS	5105-MCM-PDPS	5305-MBP-PDPS	5205-MNET-PDPS			6201-WA-PDPS	
PROFIBUS DPV1										5304-MBP- PDPMV1	5204-MNET- PDPMV1				
ProSoft Wireless Protocol		6207-WA-HART	6227-WA-HART						6201-WA-MCM		6201-WA-MNET	6201-WA-PDPM	6201-WA-PDPS		